



FRWRD

- 75F16-6 TORQUE TUBE BEARING SUPPORT
- 75C1-1 LINEAR ACTUATOR MOUNT
- 75C1-2 LINEAR ACTUATOR
- 75C1-3 LINEAR ACTUATOR CONTROL ROD
- 75C1-4 MIXER BEARING
- 75C1-5 MIXER BEARING SUPPORT
- 75C1-6 CONTROL MIXER
- 75C1-7 FLAPERON BELLCRANK
- 75C1-8 FLAPERON BELLCRANK BEARING
- 75C1-9 FLAPERON BELLCRANK BUSHING
- 75C1-10 VERTICAL FLAPERON CONTROL ROD

- 75C2-1 HORIZONTAL FLAPERON CONTROL ROD
- 75C2-2 CONTROL ROD BUSHING
- 75C2-3 REAR TORQUE TUBE BEARING
- 75C2-4 REAR TORQUE TUBE BEARING DOUBLER
- 75C2-5 TORQUE TUBE
- 75C2-6 ELEVATOR BELLCRANK
- 75C2-7 ELEVATOR CONTROL TUBE
- 75C2-8 CONTROL STICK BUSHING
- 75C2-9 STOP RING
- 75C2-10 FLAPERON CONTROL SPACER

- 75C3-1 FRONT TORQUE TUBE BEARING
- 75C3-2 CONTROL STICK
- 75C3-3 ELEVATOR CONTROL TUBE BUSHING
- 75C3-4 RUDDER PEDAL
- 75C3-5 S.S. PIANO HINGE
- 75C3-6 CENTRAL PEDAL BEARING
- 75C3-7 LATERAL PEDAL BEARING
- 75C3-8 BRAKE CYLINDER SUPPORT
- 75C3-9 TOE BRAKE PEDAL
- 75C3-10 STEERING ROD

STOL
 CH 750

CONTROLS
 EXPLODED VIEW

75-CX-1