



|         |                       |
|---------|-----------------------|
| 75T3-1  | ELEVATOR TIP RIB      |
| 75T3-2  | ELEVATOR NOSE RIB     |
| 75T3-3  | ELEVATOR REAR RIB     |
| 75T3-4  | BENT STRIP            |
| 75T3-5  | ELEVATOR SPAR         |
| 75T3-6  | HORN ANGLE            |
| 75T3-7  | ELEVATOR LOWER HORN   |
| 75T3-8  | ELEVATOR UPPER HORN   |
| 75T3-9  | ELEVATOR HINGE PIN    |
| 75T3-10 | ELEVATOR REAR CHANNEL |
| 75T4-1  | ELEVATOR NOSE SKIN    |
| 75T4-2  | ELEVATOR REAR SKIN    |
| 75T4-3  | ELEVATOR TRIM TAB     |
| 75T4-4  | E. TRIM TAB CHANNEL   |
| 75T4-5  | E. TRIM TAB HINGE     |
| 75T4-6  | E. TRIM TAB HORN      |
| 75T4-7  | ACCESS HOLE COVER     |
| 75T4-8  | E. HINGE BUSHING      |

STOL  
CH 750

ELEVATOR  
EXPLODED VIEW

75-TX-2

copyright © 2008 CHRIS HENITZ

zenithair.com

DATE: 05/09